



TO BE COMPLETED BY THE INSPECTOR FOR EACH BUILDING SEWER
 SAMPLE SITE SKETCH. GIVE DIMENSIONS FOR ALL UNDERGROUND PIPES. MAKE A DIFFERENT SKETCH FOR EACH UTILITY, IF NEEDED. FOR EXAMPLE, IF THIS HOUSE HAD DOWN SPOUT LEADERS, A SEPARATE STORM SHEET WOULD BE NEEDED.



SERVICE CONNECTION LOCATION REFERENCE (BUILDING IN PLACE)

REVISIONS:	DATE
	APPROVED: FEB. 2002
	PAGE No. 900-14